

[Click Here](#)



User Manuals, Guides and Specifications for your Brother P-touch HOME&HOBBY Label Maker. Database contains 1 Brother P-touch HOME&HOBBY Manuals (available for free online viewing or downloading in PDF): Service manual . A label maker is a helpful tool that may help you organize your house, workplace, or work environment. Even if you're ready to invest in your label maker, how much do you know about them? You may be worried that once you've labelled all of your boxes, the labels will start to peel off. When it comes to learning, experience is a powerful tool. The Brother P-touch label maker series includes more than 70 distinct types, ranging from hand-held to desktop. The hand-held label makers are small enough to fit in the palm of your hand. Although there are many specific types, most of them operate on the same basic principles. As a result, we've created a table with some of the most common issues and solutions for how to fix Brother label maker tape. By printing a label using the Brother P-touch label maker, you may run into the same or comparable issues. The label is not printed after hitting the Print key in some cases. Through the printed label, a blank horizontal line is shown. There are several more issues, etc. More Troubleshooting Guide On Brother: Brother MFC Printer Not Printing A Brother P-touch Label Printer will not allow this to occur. Lamination formulas for each label have been developed to withstand temperatures as low as -40 degrees Fahrenheit and chemicals and dampness. You may finally organize your garage, shed, and even your wet basement using a Brother label machine. In the Brother P-touch line of label makers, which comprises machines ranging from handhelds to desktops, more than seventy different configurations are available. The hand-held label makers have a compact design, making them simple to transport to any location. On the other hand, desktop computers are much larger and must be used and handled while seated at a desk. Even though there are many different models, they are all organized according to the same core operational principles. The following article summarizes some of the most common problems with Brother label maker tape, as well as potential solutions. It is one of the most common problems of this machine. If you see striped tape on a cassette label, replace it since you've reached the end of the tape. Replace all batteries or directly connect the P-touch label maker to the AC adaptor. Here is another prevalent problem Brother p touch label maker won't turn on. You can't get your label printer to switch on no matter what you try. If your label printer doesn't switch on, ensure the batteries are put correctly, with the positive and negative poles facing in the same direction. Look for the batteries and double-check that they're correctly inserted. If the screen stays dark after testing and changing the batteries, the adapter's connection may be an issue. Locate the adaptor and double-check that it is connected properly. The screen is damaged even when the system is turned on; thus, it remains dark. Replace the screen and power up the device again. It may be impossible to push the ON button if the faceplate is cracked. Then you must replace the faceplate. That is another issue users face. The primary cause could be Brother p-touch label maker tape jammed. In addition to entering the text, check to see that the tape cassette is positioned correctly and sufficient tape remains to finish the job. It is possible to clip a curved section of the tape and then thread it through the exit slot. The correct way to unstick a tape involves removing the tape cassette, gently removing the stuck tape, and then cutting the tape after it has been removed. The problem starts with printing fails on your printer. Brother P-touch label maker turns off when printing. When the PRINT key is hit, the machine frequently switches off, indicating weak batteries. The batteries must be replaced as a solution because an expended or expired battery may harm the machine's functioning. So, all four batteries should be replaced with NEW 'AAA' alkaline batteries when replacing them. The paper will not print if the tape becomes caught above the tape guides. This happens when the label is taken from the printer rather than cut. Make sure the tape feeds beneath the tape guides to correct the problem. The tape guides are on the cassette rather than on the label printer. If the cutter unit is missing, the tape may feed in the wrong direction and jam. The cutter unit consists of two green plastic pieces positioned near the printer's tape feed slot. Check out the cutter blade replacement guide if you're not sure where this is. If you press down on the cutter lever and it does not bounce back about 3/4 of an inch, it is stuck. Replace the cassette tape. Examine whether the cutter level returns to its original place. It's worth noting that if the rear panel isn't entirely closed, the cutting lever will not move. When you wish to remove all saved label files or if your P-touch labeler isn't working correctly, you may reset the internal memory of your P-touch. That is how you reset your brother's p touch label maker. Turn the P-touch off. Press the Power key while holding down the Shift and R keys to turn the P-touch back on. Release the R and Shift keys. If you wish to clear your label maker, you can also do that. First, select the rows you want to erase while holding down the Ctrl key. Select Delete Contact or Delete Record from the context menu when you right-click a row for P-Touch Editor. If no text is supplied, the label will not be printed. Is the tape cassette adequately placed, and is there enough tape left? Make sure that the tape cassette is appropriately placed and enough tape left. A dirty sensor is frequently the cause of blank label printing. Labelwriters like this use thermal printing processes to print labels. They scan the label paper for chemically treated spots that darken when applied heat. On the desktop, double-click the P-touch Editor icon. You can also follow the following approach to start the -Double-click Macintosh HD, then Applications, then P-touch Editor, and finally the P-touch Editor icon. The P-touch Editor begins. You have to remove the label marker's batteries. Then pull the tape cassette out of the device with care. Remove any fragments of labels or extraneous items that may have become stuck within the label maker with a pair of plastic tweezers. When trying to print a label using a Brother P-touch label printer, you may run into the same issue or one that is very similar to a problem that has already been encountered. If this happens, you may want to examine the list of the frequent issues that occur with the Brother label maker tape and the solutions to those issues that were shown earlier in this section. Got a question? The answer is likely here. Self-Serve Support Ask a Question Live Chat Register Your Product My Questions Does this apply to your machine? Click here to find out. PTouch PT1230PC PT1500PC PT1650 PT18R PT1950 PT1960 PT2100 PT2100C PT2110 PT2300 PT2310 PT2430PC PT2600 PT2610 PT2700 PT2710 PT2730 PT2730VP PT3600 PT9500PC PT9600 PT9700PC PT9800PC Quick Labeler QL1050 QL1050N QL1060N QL500 QL550 QL570 QL570VM QL580N QL650TD QL700 QL710W QL720NW TD2020 TD2120N TD2130N TD4000 TD4100N To change or manual adjust length, click the check media icon to make sure the layout and the label size in the machine is matching up and then click upper or down arrow in the Auto to change the length. La version française sera disponible sous peu / The French version will become available shortly Change the label settings in the P-touch Editor. The size of labels (width) selected in the P-touch Editor must be the same as the size installed in the label printer. Macintosh 1. Select the label printer under Printer on the left side. 2. Under Print Media, either click the Check Media button to detect the roll size or select the roll size from the drop-down list. 3. Auto length is set by default. To set a specific label length if using a continuous roll, select Set Length and enter the length. 4. Set the Margin if needed. Windows 1. Click File → Printer/Page Setup. 2. On the Printer Setup tab, make sure the label printer is selected. 3. Click the Page Setup tab. 4. Auto length is set by default. To set a specific label length if using a continuous roll, remove the check next to Auto and enter the length. 5. Next to Width, either click the Check Media button to detect the roll size or select the roll size from the drop-down list. 6. Under Orientation, change the orientation if needed. 7. Under Margins, change the margins if needed. 8. Click OK. Products Quick Labeler QL1100 QL1110NWB 1. In the Ptouch Editor, select Inspector on the top right to open the settings. 2. Click the Paper tab at the top of the Inspector window. 3. Make sure the label machine is selected as the printer. 4. Under Media size, click the Detect Size and Color button to detect the roll size and color. 5. Set the Length if desired. A check in the Auto Length box, will automatically adjust the length depending on the text length. 6. Set the Margins if desired. 1. In the PTouch Editor, Click File → Printer/Page Setup. 2. On the Printer Setup tab, make sure the label machine is selected as the printer. 3. Click the Page Setup tab. 4. Click the Check Media button to detect the roll size. Click OK. 5. Set the Length if desired. A check in the Auto Length box, will automatically adjust the length depending on the text length. 6. Set the Margins if desired. 7. If using DK2251 black/red tape, turn on Color Printing: a. Click the Paper tab near the top. b. In Express mode, under Two-Color Mode, select On to print on black/red tape. Or In Professional mode, click the Print Color Mode button to change to Color Mode. 1. Press the Function key. 2. Press the Left or the Right arrow key until Label length is displayed. 3. Press the Enter key (between the arrow keys); the current label length will be on the display. 4. Press the Left or the Right arrow key until the desired length is displayed. You can also enter the desired length with the number keys. Note: The Length of a label can be set from 1.2 inch up to 12 inches; the default is Auto. Note: To return to Auto press the Space bar key (below the X key). In Auto the machine will automatically change the length to fit the text. 5. Press the Enter key to apply the selected length. Note: The machine will automatically decrease the font SIZE to make the text fit onto a fix Length label. You can change the font Width to 1/2; the height of the font remains the same, but the width decreases 1/2. This will allow more characters to squeeze onto a fix Length label, while the height of the characters still remain the same. Note: If the amount of text does not fit the label length, the error message Text Too Long! will appear on the display. The amount of text needs to be decrease or increase the Label Length. Note: After the label is printed, cut along the two dots (.) printed at the beginning of the label with scissors so that the length of the label will match the setting of the machine. La version française sera disponible sous peu / The French version will become available shortly Do you like labeling your things and using a Brother P touch label? Are you having trouble searching how to change the font size on Brother P touch? Well! You are in the right place. Technology has indeed made life a lot easier. One of the best examples you can see is with printers. You can print anything and everything directly from the web page or your gallery with the help of printers. Whether it is about printing a document or a small label, keeping up with the font size becomes necessary. While organizing your personal things or something in your office, labels can help at a certain level. Printing labels is not the same as printing any document. The font size, style, color, etc. of a label may vary from that of a document. Using your favorite font can make the organizing process a lot more interesting. This may include organizing groceries or making crafts at your home, or organizing cables and files at your office. This article provides information on how to change the font size on Brother P touch in a few simple steps. However, it is important to first understand about basic features of Brother P touch. Brother P touch is a label printer that helps you make creative and more personalized labels. It is designed to be portable and easy to use and to make labeling effortless both at home and in your office. Brother P touch is a product of the company named Brother, a Japanese origin company that was founded in 1908. Being a leading brand Brother produces very new and qualitative products for printing and labeling. The company manufactures printers, portable printers, labeling machines, scanners, fax machines, and so on. Brother P touch is the series of labeling machines by Brother. The P touch machine is a versatile electronic labeling machine that is also connectable to a PC. The machine has a large keyboard that makes it convenient to type and use. It also has one-touch formatting keys. These help you save time while adding frames or changing other options and also has a backlit display. The P touch machine has access to a wide variety of built-in fonts, symbols, frames, barcodes, and templates that help you create a variety of labels for different purposes. You can easily connect the P touch device to your computer to give your labels a more personal touch or create more professional-looking labels. You can also change font styles and sizes to create better looking labels. Procedures on how to change the font size in a Brother P touch is mentioned later in the article.The company Brother also manufactures various tapes for printers in its TZe series. P touch machine also works with the easy-peel and laminated TZe series tapes which can be up to 18 mm wide. These labels are designed to be used both for indoor and outdoor purposes. It comes with more than 30-40 varieties of tapes to choose from along with flexible ID, fabric iron-on, and extra strength adhesive. The P touch machine has a large internal memory. It lets you save your most commonly used labels and reprint them anytime you want with just pressing a few buttons. There are various versions of Brother P touch label makers available in the market. Some well known Brother P touch label printers are as follows: Brother P touch PT-D210: This label maker type has a lot of functionality at a very good price. It has access to more than 14 fonts, 95-97 frames, 600 symbols, and more than 25 templates. You can also print floral or dot designs for a more decorative look. It consists of a window in which you can preview your designs before printing them. The machine is powered by six AAA batteries. This P touch machine is lightweight and portable. Brother P touch PTD6100: This portable label maker has a large QWERTY keyboard and angled design that helps create texts for labels easily. It can be connected to a PC or Mac using a USB cord. With the help of the P touch Editor Software for label designing, you can easily design labels on your computer. This machine also helps print high-resolution barcodes and logos on labels. This P touch machine can print labels at a fast speed and the labels are cut automatically. It uses over 700 symbols, 14 fonts, etc., and has a colored backlit graphic display for a better review of your designs. It is a slightly costlier version than other P touch versions. Brother P touch PTH110: This label maker is very affordable, lightweight, portable and simply consists of three fonts, five patterns, 250 frames, etc. It has 10 pre-designed labels and with a small amount of customization, it allows you to create labels within seconds. There are over 70 varieties of models of Brother P touch label printers but the above listed are some of the most used label printers. Besides these varieties, there are Brother P touch Cube Plus printers which don't have a keyboard and a screen. It works with Bluetooth technology using mobile phones, laptops, tablets, or computers through its application. The customization of fonts, colors, frames, etc. can be done through its application. Before knowing how to change the font size on the Brother P touch, it is necessary to have knowledge about how to use a Brother P touch machine. Even though there's a huge variety of Brother P touch label-making machines from handheld models to desktop ones, most of them have the same operating procedure. At first insert batteries into your P touch machine battery compartment and the use of battery varies with the type of P touch model. You can also use an AC adaptor to use electricity instead of batteries for your label maker. Into the cassette tape compartment present on the bottom of the label maker, put a new tape cassette. Pull down the lever to secure the tape and close the tape chamber. Then press the buttons "Code" and "Feed" and switch on the label maker by clicking the "On/Off" switch.Pressing the "Code" and "Style" buttons you can choose your desired font style. Similarly, by pressing the "Code" and "Size" buttons you can select the desired font size.Start typing using the letter buttons on the keyboard the way you use your computer and mobile keyboard.If you want to view your message then press the "" keys. By pressing the arrow key you can scroll and check your message and make changes if necessary. The window will only show six characters.To print your message, press the "Print" key. This will prepare your label with your written message.By pressing the "Code" and "Clear" buttons you can erase your message once you are done printing. Procedures on how to change the font size in a Brother P touch label maker are very easy and can be done with the help of the following steps: Click on the Font (Fn/F) key on the P touch label maker keyboard.Click on the Up/Down arrow keys to highlight the present size selection or click on the Left or Right keys until the term "Size" is displayed.Then press the "Ok" or "Enter" key.Click on the Left or Right () arrow keys to change the size of the font to your desired size.Then click on the "Ok" or "Enter" to confirm or save the changes made.The changed settings will be applied to the entire writing. To know about how to change the font size in Brother P touch application you should follow the steps written below:- Open the editor application and click on the icon "A text" on the screen.To change the font size, select the block of text you want to change.Click on the "Font" option. A dropdown menu will appear with different font sizes. You can select the desired size you want for your label.You can increase and decrease the size of the font with the help of "A with an arrow up" and "A with arrow down" icons present near the font size. Printing out labels from web browsers can be very problematic, and you may also face problems related to resetting the font style, font size, Frames, symbols, etc. Technology has made it easier by creating different printers for different purposes. The Brother P touch label printer is one of the best examples of a great, multipurpose label printer. Its various features have also made it easier to create labels of your own choice with your touch-up, the labels that you can use both at your home and office. Its various features also include the answer to your question on how to change the font size in Brother P touch along with the font style. With the help of the above-mentioned procedures, you can easily change the font size of the label message you want to print. The diverse models of Brother P touch don't make them difficult to use. The basic functions of every model are the same, and you can conveniently change the font size in a Brother P touch and print out your label easily.