

Continue

























Hi, I recommend performing a reset of the printer. While the printer is on, unplug the power cord from the printer. While the power is off, press the power button 5 times. After 60 seconds plug the power cord back in and power on the printer. If the error does clear, the printer has experienced an internal hardware error and it would require service. If your printer is in it's 1 year warranty, I recommend reaching out to Canon support for this issue. You will need to register your Canon gear HERE to access additional support options. If the printer is out of warranty, you would qualify for the Canon Upgrade program. This is for out of warranty units which have been diagnosed to require service or are incompatible with a new or upgraded system. This program allows you the opportunity to purchase a replacement product discounted from the list price. Free ground shipping is included with your purchase. If you would like to take advantage of this offer, please call our Sales Department at (866) 443-8002 Mon-Sat, 9 AM to 9pm EST excluding holidays. Did this answer your question? Please click the Accept as Solution button so that others may find the answer as well. Errors on printers can be frustrating, especially when you're in the middle of a critical task. One of the common issues users encounter with Canon printers is the Error E05. This error typically indicates a problem with the ink cartridges or the printing mechanism itself. In this comprehensive guide, we'll dive deep into what the Canon Error E05 is, its causes, and a step-by-step troubleshooting process to resolve this issue. Understanding Error E05 Canon printers are equipped with advanced technology that alerts users when there is something wrong. Error E05 is often displayed on the printer's LED screen along with a flashing light or a specific error code. This message generally indicates one of the following issues: Ink Cartridge Problems: E05 may indicate that the printer cannot detect one or more of the ink cartridges. Cartridge Compatibility Issues: Using third-party cartridges may lead to detection problems. Mechanical Issues: Sometimes, the error can result from internal malfunctions related to the printer's cartridge holder or print head. Identifying the specific cause of the E05 error is crucial for resolving it effectively. Causes of Error E05 Improper Installation of Ink Cartridges: One of the most common reasons for the E05 error is that the ink cartridges are not installed correctly. This can happen during the initial setup or when cartridges are replaced. Incompatible or Non-genuine Cartridges: Using ink cartridges that are not compatible with your Canon printer model can lead to detection issues. Ink Cartridge Sensors: Dust or residues on the cartridge sensors can prevent the printer from accurately detecting the cartridges. Printer Firmware Issues: Occasionally, a software glitch within the printer's firmware can trigger error codes, including E05. Damaged Cartridges: Cartridges that are damaged or empty can also result in this error. Step-by-Step Troubleshooting for Error E05 Now that we have a clearer understanding of the error, let's go through detailed steps to resolve it. Step 1: Power Cycle Your Printer Sometimes, resetting your printer can resolve temporary glitches that trigger error messages. Turn Off the Printer: Press the power button and wait for the printer to shut down completely. Unplug the Printer: Disconnect the power cord from the wall outlet or back of the printer. Wait: Leave the printer unplugged for at least five minutes to clear any residual memory. Reconnect and Restart: Plug the printer back in and turn it on. Check if the error persists. Step 2: Check Ink Cartridge Installation Incorrect installation of ink cartridges is a leading cause of Error E05. Ensure that cartridges are properly seated. Open the Printer Cover: Lift the top cover to access the ink cartridges. Remove Cartridges: Gently press down on the cartridge locking tab to release the cartridge. Carefully lift it out. Inspect the Cartridges: Check for any physical damage, like leaks or cracks. Ensure that the protective tape covering the cartridge is fully removed. Reinsert the Cartridges: Align the cartridges with their respective slots and gently push them down until they click securely into place. Close the Printer Cover: Make sure the cover is entirely closed and pressed down. Restart the Printer: Turn the printer back on and check for the error. Step 3: Clean the Cartridge Contacts and Printer Sensors Dirt or ink buildup can cause communication issues between the cartridges and the printer. Open the Printer Cover: Access the cartridges again. Use a Lint-Free Cloth: Dampen a lint-free cloth with isopropyl alcohol. Wipe Contacts on Cartridges: Gently clean the copper contacts on the cartridges. Clean Printer Sensors: Look for the print head and carefully wipe the sensors with the cloth as well. Let It Dry: Allow the cleaned parts to dry for a few minutes before reinserting the cartridges. Finalize Installation: Reinsert the cartridges and close the printer cover. Power On: Turn on the printer and check for the error. Step 4: Check for Firmware Updates Sometimes, a firmware update can resolve internal errors and glitches. Connect to Your Printer: Ensure your printer is connected to the internet (for wireless models) or directly to your computer using a USB cable. Visit Canon's Official Website: Navigate to the support section and enter your printer model to find any available updates. Download and Install Updates: Follow the provided instructions to download and install any firmware updates. Restart the Printer: After the update, restart your printer and check if the error has been resolved. Step 5: Test with New or Genuine Cartridges If the error persists, the cartridges might be the issue. Obtain New Cartridges: Purchase genuine Canon cartridges that are compatible with your printer model. Install the New Cartridges: Follow the installation procedures outlined in Step 2. Check for the Error: Restart the printer and see if the issue is resolved. Step 6: Contact Canon Support If none of the previous steps worked, the printer may require professional service. Gather Information: Note down the exact model number of your printer and the steps you've already taken. Visit Canon's Support Page: Navigate to Canon's official support website for assistance options. Contact Customer Support: You can find their hotline, online chat, or email support options. Preventive Measures Once you've resolved the E05 error, there are several best practices you can adopt to prevent future occurrences: Use Genuine Cartridges: Always opt for authentic Canon cartridges to ensure compatibility and performance. Routine Maintenance: Regularly check the printer's internal components and clean them to avoid dust buildup. Stay Updated: Keep your printer firmware up-to-date to minimize glitches. Store Cartridges Properly: If you need to store ink cartridges, ensure they are kept in a cool, dry place. Conclusion Error E05 can be a frustrating experience for Canon printer users, but with the right troubleshooting steps, it can often be resolved quickly. Proper installation of ink cartridges, cleaning of contacts and sensors, and keeping your printer updated are vital in preventing this error in the future. If all else fails, don't hesitate to contact Canon support for professional help. The key is to remain calm and systematic in your troubleshooting process to restore your printer to optimal performance quickly. By following these steps and guidelines, you can return to printing with peace of mind, knowing you have the tools to tackle such issues when they arise. Also, both ink cartridges must be inserted. You cannot use the PIXMA TS3522 with only one ink cartridge inserted. Lastly, please take the ink cartridges out of your printer and look on the bottom of each ink cartridge to make sure that the orange tape was removed. If you have performed these steps with multiple sets of color and black ink cartridges and the E 0 5 error persists, your PIXMA TS3522 would require service. If your PIXMA TS3522 was purchased less than a year ago, please contact one of Canon's Technical Support Representatives via phone or chat to obtain your in warranty options. To contact a Technical Support Representative, please use the link below to log into your My Canon account: logged in, click on your PIXMA TS3522 and then click on the Product Support button. When that page loads, click on either the Phone Support button or the Chat Support button to access support. If your PIXMA TS3522 is out of warranty, you are eligible for Canon's Upgrade Program. This is for out of warranty units which have been diagnosed to require service, or for some reason are incompatible with a new or upgraded system. This option allows you a one-time opportunity to purchase a replacement product, discounted from the list price.If you would like to take part in this option, please call our Sales Department at (866) 443-8002 Monday through Saturday, 9am to 9pm. Let them know you have been working with technical support and the Canon Upgrade Program was offered. Did this answer your question? If so, please click the Accept as Solution button below so that others may find the answer as well. Hey! Do you use Canon Printer? And stuck with the error E05 Canon Printer then you are at the right place. In this article, you will learn how to fix E05 canon printer error. The Canon error code E05 is a common error and nearly 50% of canon printer users encounter this error. So, before we fix this error, let's look at the causes why this E05 printer error occurs. Why I am getting E05 Canon Printer Error? The main reason leading to the E05 Canon printer error is due to a compatibility problem in the ink cartridge installed in the Canon printer. In Canon printer, there is an ink cartridge from which ink passes from the small opening that ink used to print papers, banners, etc. Therefore, if you don't use the printer for a long time, ink may dry out and block the cartridge opening. Another reason for this Error E05 is a malfunction in a cartridge holder or when replacing the cartridge. This error is common and can be easily fixed. Continue to read this article to learn How Canon printer comes out of error state? How Do I Fix E05 Error on Canon Printer? Solution 1: Switch off the canon printer If you are facing this E05 Canon printer error, the common solution to fix this error is to Switch off the Canon Printer. Sometimes due to overheating, you may lead to error E05. Press the Stop button 5 to 6 seconds to reboot the Canon printer. Now, Start your Canon printer it is ready to use. If the error still remains then move on to the next solution. Solution 2: Factory Reset your Canon Printer You can Factory reset your Canon printer to troubleshoot error code E05. Factory setting can restore settings to their initial state, it will erase all the settings & specifications from your Canon printer. However, Factory restart is the most effective and easy way to get rid of all problems & error message: For the factory reset option, start your printer. Now, open the menu bar option Use the directional arrow to navigate the Setup menu. Move to Device settings and click OK Now, select the re-setting option & hit OK to start the factory reset. After completing this process Check whether the E05 canon printer errors exist or not. If it still there, then move on to the next solution. Solution 3: Check the Cartridge Position The E05 Canon Printer Error may be due to incorrect cartridge position. Sometimes we take out the cartridge and force it back to the wrong position, it can also damage your cartridge. So you can remove the cartridge and then reinstall it. Make sure the condition of the ink cartridge fits and is accurate. Solution 4: Reinstalling & Clearing the Blockage of Ink Cartridge. Sometimes due to dust particles or dry ink leads to this error code E05 on Canon printer. You have to reinstall and clean the Blockage of the cartridge. Follow the instructions: First, you have to take out the cover of the Canon printer. Switch off the printer using the power button. You will see an ink cartridge install Press 2 times on the lock which is located side of the cartridge holder. After that take out the ink cartridge. Clean the ink cartridge, using a soft clean piece of cloth, carefully wipe the "golden metallic strip" which is located on the front part of the cartridges. Now reinstall the ink Cartridges. Restart the Canon printer Cartridge helps the Canon printer to read any instructions. Hence, make sure the ink cartridge is properly clean. If error still remains then try the next solution it you to fix Canon error code E05. Solution 5: Wrong & Damage ink cartridge installed If the Damage or wrong ink cartridge installed can also lead to E05 Canon Printer Error, if it happens then you have to purchase the correct ink cartridge and install it properly on the side of the cartridge packaging. FAQ: Learn More About Canon Printer The canon printer error E05 means that cartridge is corrupted or the contacts are dirty. So, when the error E05 appears first try to clean the contacts on the cartridge and check if it working. But if still the error appears, then replace the cartridge. E5 is a printer error for Canon printers and states a problem with an ink cartridge. The E5 printer error indicates that the Ink cartridge is not installed properly or the ink cartridge is unsupported. The canon printer error appears when the Canon printer is facing issues with the cartridge installed in the printer or the cartridge is not installed properly. If the cartridge is jammed in the drum and unable to move. And in some cases, if the cartridge is not injected in the printer, then this start showing different printer errors like E04, E05, E14, & E15 Conclusion: In this article, I hope you get all your answer related to Error code E05. Follow the instruction given one by one to solve E05 Canon Printer Error, and you can easily use the Canon printer without any problem. I will like to thank you to read this article and show your trust & love. You can also connect with us on over Facebook page. Good Luck. I Hardeep has always been a Windows lover ever since she got her hands on her first Windows XP PC. She has always been enthusiastic about technological stuff, especially Artificial Intelligence (AI) computing. Before joining PC Error Fix, she worked as a freelancer and worked on numerous technical projects. The Canon printer error E05 shows up mainly when the ink cartridge is dirty, not installed correctly, or not compatible with your printer. The dirtiness is usually a result of dried ink that accumulates internally when the printer is not in use for extended periods. You can fix the E05 error on your Canon printer following straightforward steps, which I will show you in this post.How to fix Canon Printer Error E05 on Windows PCHere are the solutions to get rid of the E05 error when you use your Canon printer. I recommend that you apply these solutions in the order in which I've laid them out.Reboot the printer.Factory reset the printer.Reinstall and clean the cartridge.Replace the ink cartridge.I will elaborate on these solutions and provide answers to questions you may have on this issue.1) Reboot the printerThe first step in troubleshooting the Canon printer error E05 is to reset the printer. With the printer ON, press and hold the Stop button for around 5 seconds until it starts rebooting.Allow the printer to reboot completely, and you can now test it again to see if the error persists. If you keep getting the error E05, continue with the next solution.2) Factory reset the printerLike most other devices, a factory reset brings the printer back to the default configuration in its original state. Factory resetting your Canon printer will fix the E05 error if it's caused by misconfiguration. Here's how to do it:Power ON your Canon printer and go to the menu bar option. Using the arrow keys, go to Setup menu.Next, navigate to Device settings and then hit the OK button. Finally, choose the Reset option and click on OK.Allow the printer a moment to complete the factory reset and test to see if this has solved the problem.3) Reinstall and clean the cartridgeThe cartridge is responsible for reading instructions sent to the printer. Whether you use your printer often or once in a while, particles can form in it due to the error you are experiencing now. It is a good practice to clean the ink cartridge regularly to prevent such issues.To clean your Canon printer ink cartridge, power OFF the printer and place it on a flat surface and open the lid of the printer. Here, you will find an ink cartridge install. Use your fingers to press the two click-locks at the side of the cartridge holder simultaneously. This makes the ink cartridge come out easily.Next, examine the ink cartridge for signs of debris, dried ink, dust, or any particles that can obstruct the cartridge. Using a lint-free material or soft tissue, clean the golden metallic strip on the front side of the cartridges and get rid of all the blocking particles.After clearing the particles, you can now reinstall the ink cartridges you removed earlier and then reboot the printer.4) Replace the ink cartridgeReplacing the ink cartridge on your Canon printer is another way to fix the E05 error. This is because you might be using the wrong ink cartridge or the one installed is damaged.When every other solution fails, you have to pay a visit to an electronics shop and purchase new ink cartridges for your printer.Related: Fix Canon Printer Error 5C20.What is the meaning of Canon printer error code E05?The error code E05 you encounter on your Canon printer arises when the ink cartridge is dirty, incompatible with your printer, or not installed properly.How do I clean a Canon ink absorber?Here are the steps to clean your Canon ink absorber:Unplug the printer.Open up the printer and allow the cartridge cradle to be at the center of the printing unit.Soak the excess ink using a paper napkin or soft material.Pull the frame away from the printer and take out the ink absorber pad(s) from the frame.Replace the ink absorber pads and close the printer.How do I get rid of errors on my Canon printer?A simple reset is the first step in troubleshooting errors on your Canon printer. To do this, press and hold down the Power button for 10 seconds. This button could be named Stop, Reset, or Resume, depending on the printer model. Canon printers are renowned for their reliability and high-quality printing, but like any other electronic device, they can encounter errors from time to time. One common error that Canon printer users may come across is Error Code E05. This error is typically associated with ink cartridge issues and can prevent the printer from functioning correctly. In this blog post, we will delve into the causes behind Canon Printer Error Code E05 and provide effective solutions to resolve it.Understanding Canon Printer Error Code E05The Canon Printer Error Code E05 indicates that the printer is experiencing an issue with the ink cartridges. It commonly occurs when the printer fails to recognize or detect the installed ink cartridges, leading to printing problems or the inability to print altogether. This error code is often accompanied by flashing or blinking lights on the printer control panel.Causes of Canon Printer Error Code E05Several factors can contribute to the occurrence of Canon Error E05. Some of the most common causes include: Incorrect installation of ink cartridges: If the ink cartridges are not properly installed or seated in their respective slots, the printer may fail to detect them, triggering the E05 error. Incompatible or non-genuine ink cartridges: Using ink cartridges that are not compatible with the Canon printer model or are not genuine Canon cartridges can lead to Error Code E05. The printer may not recognize these cartridges, causing the error to occur. Low ink level: When the ink level in the cartridges drops to a certain threshold, the printer may display Error Code E05 to indicate the need for cartridge replacement.Solutions to Resolve Canon Printer Error Code E05: Check ink cartridge installation: Start by turning off the printer and opening the printer cover or cartridge access panel. Ensure that the ink cartridges are properly installed and securely seated in their designated slots. Gently push each cartridge down until it clicks into place. Close the printer cover or cartridge access panel and turn on the printer to check if the error has been resolved. Verify cartridge compatibility: Ensure that the ink cartridges you are using are compatible with your Canon printer model. Refer to the printer manual or visit the Canon website to confirm the correct cartridge types and numbers for your specific printer. If you are using non-genuine or third-party cartridges, consider replacing them with genuine Canon cartridges to eliminate any compatibility issues. Replace low or empty ink cartridges: If the ink level in any of the cartridges is low or empty, replace them with new cartridges. Open the printer cover, remove the empty cartridge, and insert a new one according to the manufacturer's instructions. Close the printer cover and power on the printer to check if the error persists. Restart the printer: Sometimes, a simple restart can resolve the E05 error. Turn off the printer, unplug the power cord from the power source, wait for a few minutes, and then plug it back in. Power on the printer and check if the error message disappears. Reset the printer: If the above steps do not resolve the issue, you can try resetting the printer to its default settings. Consult the printer manual or visit the Canon support website for specific instructions on how to perform a factory reset. Note that this may erase any custom settings or configurations you have made on the printer. Contact Canon support: If none of the above solutions work, it is advisable to contact Canon's customer support for further assistance. Their technical experts can provide specific guidance tailored to your printer model and help you resolve the Error Code E05.ConclusionEncountering Canon Printer Error Code E05 can be frustrating, but with the right troubleshooting steps, you can overcome this issue. By following the solutions outlined in this blog post, you can effectively address ink cartridge-related problems and restore your Canon printer's functionality. Remember to use genuine Canon cartridges, install them correctly, and keep an eye on the ink levels to prevent future occurrences of Error Code E05.References: Canon Error Code E05 Error E05 in Canon printers occur due to the compatibility issue of ink cartridge installed in the printer. This Error E05 also occurs if Ink Cartridge is not installed properly. Ink Cartridge in Canon printers has a small opening through which it discharge the ink to be utilized on a certain paper, therefore, when the printer is not used for a considerable period, the ink may get dried up and block the cartridge opening. Error E05 can also be caused by the disarrangement of a cartridge in its holder, or when the cartridge needs to be replaced. This issue is common and can be solved easily.Turn on your printerHold Stop button for 5 to 6 seconds to reboot the printer.Now, it is ready for use.Open the lid cover from the rare top of the canon printer.You will see the ink cartridge installed.Press the two click-locks located at the sides of the cartridge holder, and the ink cartridge will pop-out to be taken off.Now, Check the cartridge if it is having any sort of dust particles, or have dried ink in its opening that could be causing the blockage.Clean cartridges by tissue and re-install the ink cartridge in its holder.If the error still occurs then you need to replace the ink cartridge.Buy an Ink cartridge of your Canon printer from a local electronics retailer.Re-install the cartridge by following Method1. Cara Mengatasi Error E05 Printer Canon MP258 & MP287 - Ada banyak kode error pada printer Canon MP258 yang menunjukkan letak kerusakan pada printer. Salah satunya error E05 yang menyebabkan printer tidak bisa mencetak.Cara Mengatasi Error E05 Printer Canon MP258 & MP287?Pada dasarnya error E05 mengindikasikan ada kesalahan pada bagian cartridge. Seperti diketahui cartridge pada printer merupakan salah satu komponen utama yang sangat penting karena berfungsi sebagai tempat penyimpanan dan pengatur keluarnya tinta. Namun bukan berarti harus mengganti cartridge untuk masalah ini. Jadi, jangan buru-buru membeli cartridge baru saat muncul kode ini pada printer kamu. Bagaimana cara mengatasinya?Ikuti panduan berikut ini.Cara mengatasi kode error E05 printer Canon MP258 ini juga berlaku untuk printer Canon MP287.Berikut ini beberapa penyebab munculnya kode error E05.Berikut ini langkah-langkah memperbaiki error E05 printer Canon MP258:Buka penutup atas printer dan lepas cartridge. Setelah itu pasang ulang cartridge. Biasanya error E05 hanya disebabkan oleh posisi cartridge yang kurang tepat. Hidupkan printer kembali. Jika kode error masih muncul, coba lakukan reset printer. Langkah-langkahnya akan dijelaskan di bawah.Jika setelah reset printer belum bisa mencetak, lepas lagi cartridge dan bersihkan chip cartridge dari tinta secara hati-hati.Solusi terakhir adalah ganti cartridge dengan yang sejenis. Sebaiknya pastikan terlebih dahulu sebelum memutuskan untuk membeli cartridge baru. Di bawah akan dijelaskan cara sederhana mengetahui cartridge rusak atau tidak.Umumnya error pada printer tidak perlu ganti komponen. Beberapa masalah bisa langsung diatasi hanya dengan reset printer.Berikut ini langkah-langkah reset printer Canon MP258.Hubungkan kabel printer dengan stop kontak listrik.Biarkan printer dalam keadaan off/mati.Tekan dan tahan tombol Stop/Reset dan tekan kembali sebanyak 2 kali kemudian lepas menekan sama tombol printer.Jika proses reset berhasil, printer akan memproses dan tunggu sampai muncul angka 0 di LED display.Sampai tahap ini printer telah berhasil direset.Lihat juga cara mengatasi error printer Canon IP2770/Jika masih error E05, gunakan aplikasi reset printer Canon MP258 atau MP287 sesuai tipe printer yang kamu gunakan.Berikut langkah-langkahnya:Download aplikasi resetter printer Canon MP258 service tools Canon printer MP258.Buka aplikasi resetter printer Canon.Nyalakan printer dan hubungkan dengan laptop atau komputer.Masukkan beberapa kertas pada paper tray.Klik tombol Main pada aplikasi resetter dan printer akan mencetak kertas.Klik tombol EEPROM Clear > EEPROM.Printer akan mencetak kertas sekali lagi.Matikan printer dan hidupkan kembali.Sampai tahap ini, jika tidak terjadi masalah lain pada cartridge, seharusnya kode E05 bisa diatasi.Cartridge merupakan salah satu komponen pada printer yang dapat mengalami kerusakan. Bukan hanya pada printer yang sudah berumur tapi juga pada printer baru. terlebih jika pemakainya sembarangan menggunakan print, bisa membuat cartridge lebih cepat dari seharusnya. Bagaimana cara mengetahui cartridge rusak atau tidak?Lepas cartridge dan pasang pada printer lain yang sejenis. Jika printer ini berfungsi, kemungkinan penyebabnya bukan pada cartridge. Pinjam cartridge dari print sejenis untuk mengetes printer. Jika bisa mencetak, maka penyebabnya adalah cartridge bermasalah. Bisa jadi kotor atau memang harus diganti dengan yang baru.KesimpulanCara Memeriksa Printer Canon MP258 dan MP287 Error E05 Mengatasi error E05 printer Canon MP258 sebaiknya mulai dari memasang ulang cartridge printer. Jika masih error, reset printer Canon MP258 baik secara manual maupun menggunakan software resetter.Bersihkan chip cartridge.Solusi terakhir adalah ganti cartridge. Langkah hanya setelah memastikan cartridge printer benar-benar rusak.Lihat juga cara mengatasi error P02 printer CanonDemikianlah cara mengatasi error E05 printer Canon MP258 yang juga berlaku untuk printer Canon MP287. Selamat mencoba! Anak Tekno Tertarik dengan dunia Blog dan SEO sejak 2017 dan terus belajar sampai detik ini. Hi Samuellaand! Thanks for posting in the Canon Community Forum. I see that you are unable to print to your PIXMA TS3522 when using your new M3 computer. I see that you can print from other computers and a phone without an issue. However, when you try to tryt from your M3, the printer throws an E,0,5 or E,0,9 error. You also mention checking the ink cartridges and you see no issue. These errors indicate a cartridge issue and protective tape inside the printer. Since this is only happening with your M3, it means that computer is sending information that triggers those errors. The TS3522 does not require you to install a driver on your Mac computer. It is AirPrint compatible, so you should be able to print from Mac computers, iPhones, and iPads without installing a driver. If you have not done so, you can try deleting and readding the printer. You can also try restarting your computer (turning it off and back on). To delete and add a new copy of the printer, you can follow these steps: If you print directly to the printer using a USB cable, please do the following: Click on the Apple icon in the top menu. Click on SYSTEM SETTINGS. In the left column of the window, click on PRINTERS AND SCANNERS (may need to scroll down to find it). Click on the Canon TS3500 series that appears in the list of printers. Click on the option that deletes or removes the printer. After the printer is removed from the list, click on ADD PRINTER, SCANNER, OR FAX on the right side of that window. When the Add printer window opens, click on the PRINTERS AND SCANNERS (may need to scroll down to find it). Click on the Canon TS3500 series that appears in the list of printers. Click on the option that deletes or removes the printer. After the printer is removed from the list, turn the printer back on and wait for it to finish turning on. A few minutes after the printer turns on, a new copy of the printer should automatically be added to your computer. If the printer is not added automatically, click on ADD PRINTER, SCANNER, OR FAX on the right side of that window. When the Add printer window opens, click on the Canon TS3500 series. Click on the ADD button Once the printer is added back, please try printing. If the errors keep coming back and restarting your computer does not help, and you are using a USB cable for connection please make sure that it is 6 feet long or less. We do not recommend the use of USB adapters or a USB hub or connector. We recommend that the cable be connected directly to a USB port on your computer. If your computer has oval-shaped USB-C ports, I recommend using a cable that has a USB-C connector on one end and a square USB-B end on the other (for the printer). If you are still having trouble, I recommend contacting Apple. Please let them know that you are able to print from other devices, and the errors only pop up when you use your M3 computer. I hope this information helps. Thanks again. In today's digital world, printers play a crucial role in both personal and professional settings. Canon is a well-known brand in the printing industry, thanks to its wide range of reliable printers. However, like any technology, Canon printers are not immune to errors. One common error that users encounter is Error E05, often leading to frustration and confusion. This article aims to provide a comprehensive guide on understanding, troubleshooting, and resolving Error E05 on Canon printers. Error E05 Error E05 on Canon printers is an indication of a problem with the ink cartridge, specifically when the printer detects that the cartridge has not been installed correctly, is defective, or is incompatible. Symptoms of Error E05 include blinking lights, an error message on the printer's display, or the printer refusing to print altogether. This error can occur with various Canon printer models, including inkjet and multifunction printers. Common Symptoms of Error E05 Error Message: The printer may display the message "E05" prominently on the screen, sometimes accompanied by explanations such as "wrong cartridge" or "incorrect installation." Blinking Lights: The printer's indicator lights may blink in certain patterns or may remain lit, signaling that there is an issue with the ink cartridge. Printing Failure: When attempting to print, the printer may not respond, or it may produce errors in the print job. Physical Issues: You might notice the printer making unusual noises when it tries to engage with the ink cartridges. Causes of Error E05 Understanding the root cause of Error E05 is critical for effective troubleshooting. Here are the common reasons this error might occur: Incorrect Installation: The most common cause of Error E05 is improper installation of the ink cartridges. They need to be seated correctly in their designated slots. Defective Ink Cartridges: If an ink cartridge is faulty or has manufacturing defects, it can trigger Error E05. Incompatible Cartridges: Using third-party ink cartridges or non-genuine Canon cartridges can lead to compatibility issues that result in the E05 error. Dirty Contacts: The electrical contacts on the cartridges or within the printer can become dirty or damaged, affecting communication between the cartridge and printer. Firmware Issues: Sometimes, the printer's firmware may require an update, which can also lead to various error messages, including E05. Step-by-Step Guide to Fixing Error E05 Now that we have an understanding of what Error E05 is and its potential causes, we can move on to the solutions. Below is a step-by-step guide to help you effectively resolve this error. Step 1: Power Off the Printer The first step in addressing any printer error is turning the printer off. Unplug it from the power source and wait for at least five minutes. This allows the printer to reset. Once the waiting period is over, plug it back in and power it on. Step 2: Examine the Ink Cartridges Open the Printer Cover: Lift the printer cover to access the ink cartridges. Remove the Cartridges: Carefully remove the cartridges from their slots. Make note of which cartridge goes where. Inspect the Cartridges: Look for any visible signs of damage, such as cracks or leaks. If you find these, you may need to replace the cartridge. Step 3: Clean the Contacts Cleaning the contacts of both the cartridges and the printer may resolve the issue: Prepare a Clean Cloth: Use a lint-free cloth or a coffee filter slightly dampened with distilled water (avoid using rubbing alcohol). Clean the Cartridge Contacts: Gently wipe the gold contacts on the cartridge. Ensure no residue or lint remains on the contact area. Clean the Printer Contacts: Use the same cloth to gently clean the corresponding contacts inside the printer. Step 4: Reinstall the Ink Cartridges Reinsert the Cartridges: Firmly place the cartridges back in their respective slots, ensuring they click into place. Close the Printer Cover: Make sure the cover is securely latched. Step 5: Check Compatibility If you are using third-party ink cartridges, consider switching back to genuine Canon cartridges. Sometimes, compatibility issues can lead to the E05 error. Step 6: Update Printer Firmware Firmware issues may also lead to errors. Check Canon's official website for any available firmware updates for your printer model. Visit the Canon Support Page: Enter your printer model and look for firmware updates. Download the Update: Follow the instructions for downloading and installing firmware updates. Step 7: Perform a Factory Reset If the above steps do not resolve the issue, performing a factory reset on your printer may help. Access Printer Settings: Use the printer's control panel to navigate to the settings menu. Select Factory Reset: Carefully choose the factory reset option. Keep in mind that this will erase all custom settings. Restart the Printer: After the reset is complete, restart the printer. Step 8: Contact Canon Support If all else fails and Error E05 persists, it may be time to reach out to Canon's customer support. They can provide guidance based on the specifics of your model and the symptoms your printer is exhibiting. Preventing Error E05 in the Future After successfully resolving Error E05, it's beneficial to take preventive measures to avoid similar issues in the future. Here are some best practices: Use Quality Cartridges: Always opt for genuine Canon cartridges or verified high-quality third-party alternatives. Keep the Printer Clean: Regularly clean the printer, paying special attention to the ink cartridge area. Monitor Ink Levels: Replace cartridges before they run out of ink to prevent additional wear on the printer's mechanisms. Perform Regular Maintenance: Schedule periodic maintenance checks and perform necessary updates to the printer firmware. Handle with Care: Always handle the ink cartridges carefully to avoid any physical damage during replacement. Conclusion Error E05 can be frustrating, but understanding its causes and following the outlined troubleshooting steps can help you resolve it effectively. Canon printers are generally reliable, and with the right care and maintenance, you can minimize the occurrence of such errors. Always keep your printer clean, use the correct ink cartridges, and stay updated with firmware to ensure a smooth printing experience. If you encounter further issues, don't hesitate to contact Canon's customer support for professional help. By following these guidelines, you can enjoy hassle-free printing with your Canon printer for years to come. If you are facing 'e05 Canon Printer error' while trying to use your Canon Printer to print a document, then you are in right place for the solution. Here, you will be guided with easy methods to resolve the issue. Let's starts the discussion. 'e05 Canon Printer error' or 'Canon Printer Error Code E05': It is common printer error associated with Canon-model printer error. The core reason behind this error is compatibility issue of ink cartridge installed in your Canon printer. Also, 'Error Code E05' is occurred if the ink cartridge is installed or fitted properly. If you not aware, Ink Cartridges in Canon printers has small opening through which it discharge the ink to be used on certain paper. So, when your canon printer is not getting used for considerable period, then printer ink may get dried up & block the cartridge opening. Another possible reason behind this error is disarranged of ink cartridges in its holder section. Also, this error occurs if your ink cartridges needs to be replaced. However, it is possible to resolve this issue with our instructions. One simple way to fix the issue is to resetting canon printer while other solution can be installed and cleaning blockage from the rare top of Canon printer. Let's go to fix 'e05 Canon Printer error'? Method 1: Reinstall and clean the blockage of Ink Cartridges Sometimes, this issue occurs possibly due to dust particles or dry ink on your Canon printer. You can fix the issue by reinstalling and cleaning the blockage of ink cartridge. Step 1: Remove the cover of your Canon printer and turn OFF your Canon printer using 'Power' button Step 2: You will see 'Ink Cartridge Install'. Double-press on lock which is located side of cartridge holder. Once done, remove ink cartridge Step 3: Now, clean your ink cartridge using soft clean piece of cloth and wipe the 'Golden metallic strip' carefully, located on front part of ink cartridge Step 4: Once done, reinstall the Ink Cartridge and restart your Canon Printer, and check if the issue is resolved. Method 2: Correct your ink cartridge position This issue can also be occurred if ink cartridge is not placed in right position. You can fix the issue by checking and fitting ink cartridge in correct position. Once done, please check if the error is resolved. You can also try to remove ink cartridge and then reinstall it in order to resolve the issue using above method. Method 3: Restart Canon Printer One possible way to resolve the issue is to turn OFF your canon printer in order to reduce overheating and other issue, and then restart Canon printer in order to resolve the issue. To do so, press 'Stop' button 5-6 seconds to restart/reboot canon printer. Now, start your canon printer and check if the problem is resolved. Method 4: Perform factory reset your canon printer If the problem is still persist, then you can try to fix the issue by performing factory reset your Canon printer. Resetting printer will erase all the settings & specifications from your Canon Printer. Step 1: Turn ON your Canon Printer Step 2: Now, go to 'Menu Bar' option and use directional arrow to navigate the 'Setup Menu' Step 3: Move to 'Device Settings' and hit 'Ok' option Step 4: Now, select 're-setting' option and hit 'Ok' option to start factory reset operation. Wait to complete the process and once done, please check if the error is resolved. Method 5: Fix Ink cartridge hardware issue This issue can also be occurred if ink cartridge hardware is damaged or wrong ink cartridge is installed. In such case, you can purchase the correct ink cartridge and install it properly in your printer in right position. After that, please check if the problem is resolved. Fix Windows PC Problems with 'PC Repair Tool' [Recommended solution] You can fix your Windows PC problems with 'PC Repair Tool'. This software offers you to find and fix BSOD errors, DLL errors, EXE errors, problems with programs, malware or viruses issue, system files or registry issues and other types of issue with just few clicks. You can get this tool through button/link below. Conclusion I am sure this post helped you on How to fix e05 Canon Printer error with several easy step/methods. You can read & follow our instructions to do so. That's all. For any suggestions or queries, please write on comment box below.